

WATERMAID® WM44 - Quick Reference Guide

Clock Setting	<ol style="list-style-type: none"> 1. Press CLOCK 2. Press DAY and use ▼ and ▲ to select the current day 3. Press HOUR and use ▼ and ▲ to select the current hour 4. Press MIN and use ▼ and ▲ to select the current minute 5. Press CLOCK to save
Timer Setting	<ol style="list-style-type: none"> 1. Press TIMER 2. Ensure "Timers ON" is displayed. (If off, press ENTER to turn on) 3. Use ▼ and ▲ to select desired timer (1 to 6) to be used 4. Press ENTER to display desired timer screen 5. Press DAY and use ▼ and ▲ to select running day(s) 6. Press HOUR and use ▼ and ▲ to select start time hour 7. Press MIN and use ▼ and ▲ to select start time minute 8. Press TIMER and use ▼ and ▲ to set the length of operation 9. Press TIMER to save 10. Press MENU to return to the home screen or ▼ to select another timer
Disable Timers	<p>To use an <u>external</u> or hard-wired timer, all in-built timers must be disabled:</p> <ol style="list-style-type: none"> 1. Press TIMER 2. Press ENTER and "Timers OFF" will be displayed 3. Press MENU to exit 4. Press POWER to turn the chlorinator on (manual mode)
Manual ON/OFF	<p>Press POWER at any time to turn the unit on or off temporarily.</p> <p>To turn the WM44 off permanently, all in-built timers will need to be disabled; otherwise the unit will restart at the next scheduled timer event.</p>
Boost	<ol style="list-style-type: none"> 1. Press BOOST 2. Use ▼ and ▲ to select the number of boost hours 3. Press ENTER to commence boost cycle <p>To cancel boost mid-cycle, press BOOST and then ENTER to stop</p>
Backwash	<ol style="list-style-type: none"> 1. Press BACKWASH 2. Press ENTER to start backwash program and use ▼ and ▲ to select backwash time in minutes 3. Press ENTER and screen will prompt you to turn the filter multi-port valve to BACKWASH 4. Once valve is set to BACKWASH, press ENTER to continue. (To cancel: press ▼ and then ENTER twice) 5. Once backwash is complete, the screen will prompt you to set the filter multi-port valve to RINSE 6. Once valve is set to RINSE, press ENTER to continue. (To cancel: press ▼ and then ENTER twice) 7. Once rinse is complete, the screen will prompt you to set the filter multi-port valve to FILTER 8. Once valve has been set to FILTER, press ENTER to return to normal operation. Backwash is now complete.